




## LIFE

EXTERNAL BATTERY 6000

### USER MANUAL

Thanks for your support to uBear! Please, read the guide for maintenance carefully in order to protect your legal interests.

#### ■ Product Diagram



#### ■ Specifications

Model: uBear Light 6000  
Battery Type: Lithium Polymer  
Battery Capacity: 6000mAh @ /17.5Wh  
Input: DC 5V/2A  
Output: DC 5V/2.1A  
Temperature: 0°C-45°C (Working)  
Standard: GB4706.18-2005  
Protection: Short circuit, Overcharge Over discharge, Over load  
Compatibility: Made for most rechargeable USB devices  
(such as smartphones, tablets, etc.)

#### ■ Checking Battery Level

Press the switch button, the LED indicator will show the battery level.  
(Some deviations are acceptable in the following percent data.)

1. Level 0%-25%, Display one blue light.
2. Capacity 26%-50%, Display two blue lights.
3. Capacity 51 %-75%, Display three blue lights.
4. Capacity 76%-100%, Display four blue lights.

#### ■ Charging the Power Bank

Check the voltage (DC 5V) of devices or power adapters carefully before using. Re-charge your power bank once every three months when it is not in use, and fully charge it before putting it away the first time.

1. Connect your power bank using included micro USB cable. You can charge your power bank by PC USB port or using an AC power adapter. (recommended current: 2A). When connected correctly, charging will start automatically.
2. The LED indicator light flashes while charging.
3. When Power Bank is fully charged 4 LED Indicators are on.
4. After Power Bank is fully charged, please disconnect it from the power source.

#### ■ Charging USB Devices

The power bank does not have pass-through capability. Please charge the power bank separately from other devices. The power bank is plug-and-play for most rechargeable USB devices,

1. Plug the standard USB end into the power bank.
2. Use the other end of the cable and plug it into the device. When connected correctly, charging will start automatically.
3. The LED indicator light flashes while charging.
4. When the device is fully charged, disconnect it from the Power Bank.

#### ■ Trouble Shooting

If there is a short circuit, the power bank will turn off automatically, and switch to protected mode. Reset the power bank by PC USB port or using an AC power adapter (recommended current: 2A).

#### ■ Cautions and Warning & Disclaimer

Read all the instructions and warnings carefully prior to using this product.

1. Do not store the battery in a high temperature environment, including intense sunlight heat. Do not place the battery near a fire or other excessively hot environments.
2. Avoid excessive drops, bumps, abrasions or other impacts to this battery. If there is any damage to the battery such as dents, punctures, tears, deformities or corrosion, due to any cause, discontinue use and contact Manufacturer or dispose of it in an appropriate manner at your local battery recycling center.
3. Do not disassemble this battery or attempt to repair or modify it in any manner.
4. Do not expose this battery to moisture or submerge it in liquid. Keep battery dry at all time.

5. Do not attempt to charge the battery using any method or connection other than the device's USB connector.
6. Incorrect use of the Power Bank can cause the Power Bank to get hot, ignite, and can cause serious injury. Due to any cause listed, discontinue use the Power Bank and contact Manufacturer.

We have made every effort to ensure that the information and procedures in this user manual are accurate and complete. Improper use of this product may result in product damages, excess heat, fire or explosion, and cause serious injury or property damage, for which uBear (Manufacturer) is not responsible. uBear reserves the right to make any changes without further notices to any products herein.

#### ■ Package Content

- ▲ uBear power bank x 1      ▲ User manual x 1  
▲ Micro USB cable x 1

#### ■ Technical Support and Warranty

Please refer to [www.ubear-world.com](http://www.ubear-world.com) for technical support and the included warranty card for warranty information.

uBear Inc. California  
28 Valley st, Office 1045, Pasadena, CA 91105, USA  
Website [www.ubear-world.com](http://www.ubear-world.com)  
Phone +13238253023  
E-Mail [usa@ubear-world.com](mailto:usa@ubear-world.com)

## WARRANTY CARD

1 year

### Terms and Conditions

1. uBear products are subject to a warranty period (including materials and workmanship) of 12 months from the date of purchase.
2. uBear is not responsible for the repairing or replacement of products in any of the following circumstances: the defect was caused: by misuse, negligence, accident, abuse, improper installation, and misapplication; unauthorized attempts to repair or modify the product; incorrect or inadequate electrical voltage or connection.
3. All warranty services will only be provided upon presentation of the original products warranty Card with proof of purchase (dealer's receipt or invoice) in the same region where the servicing is brought in to the uBear Service Centre or its authorized service agent.
4. During the warranty period if the supply of any parts of the defect items are discontinued, customers are required to trade in the defect items for other equivalent version products.
5. uBear reserves all the rights to alter the terms and conditions without prior notice.




**LIFE**  
**EXTERNAL BATTERY 6000**

## РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ

Благодарим за выбор продукта uBear!  
Просим внимательно ознакомиться с данной инструкцией  
перед использованием.

### ■ Схема подключений



### ■ Спецификации

Модель: Life External Battery 6000  
Тип батареи: Литий-полимерный  
Ёмкость: 6000mAh  
Входной ток: DC 5V/2A  
Выходной ток: DC 5V/2.1A  
Температура в режиме работы: -10° C-40° C  
Влажность в режиме работы: относительная влажность <80%  
Сертификация: FCC, CE, PCT  
Защита от: короткого замыкания, чрезмерной зарядки/разрядки, перегрева.  
Совместимость: устройства с возможностью зарядки и разъемом USB (Такие как телефоны, планшеты и т.д.)

### ■ Проверка уровня зарядки

Когда аккумулятор подключен, индикатор показывает уровень заряда.  
1. Уровень заряда <33%, первая секция индикатора мигает;  
2. Уровень заряда <66%, вторая секция индикатора мигает;  
3. Уровень заряда <100%, третья секция индикатора миг;  
4. Уровень заряда =100%, индикатор горит полностью.

### ■ Зарядка аккумулятора

Проверьте напряжение зарядного устройства или девайса, с

помощью которого планируете заряжать аккумулятор (5V).  
Заряжайте аккумулятор каждые 3 месяца, даже если не используете его.  
В первый раз зарядите аккумулятор до 100%.  
1. Подсоедините к аккумулятору Micro USB кабель, идущий в комплекте. Вы можете заряжать аккумулятор от компьютера или используя сетевое зарядное устройство (рекомендуемая сила тока – 2 A).  
При правильном подключении аккумулятор начнет заряжаться автоматически.  
3. Индикатор мигает во время зарядки.  
4. Когда аккумулятор полностью заряжен, индикатор горит полностью.  
5. Отключите аккумулятор от устройства питания, когда он полностью

### ■ Зарядка USB устройства.

Во время зарядки аккумулятора не заряжайте от него другие устройства. Сначала зарядите аккумулятор. После этого аккумулятор будет готов к работе с другими устройствами.  
1. Подключите кабель к разъему USB-A аккумулятора.  
2. Подключите другой конец кабеля к устройству, которую планируете заряжать. При правильном подключении устройство начнет заряжаться автоматически.  
3. Во время зарядки индикатор будет гореть.  
4. Отключите устройство, когда оно будет полностью заряжено.

### ■ Защита от неисправностей.

В случае короткого замыкания аккумулятор автоматически переключится в режим защиты.  
Отключите аккумулятор от устройства питания.

### ■ Меры предосторожности

1. Не подвергать аккумулятор воздействию высокой температуры, а также прямых солнечных лучей. Использовать вдали от открытого огня или нагревательных элементов.  
2. Избегать механических повреждений устройства. При обнаружении каких-либо повреждений, деформации или

коррозии, прекратить использование устройства и связаться с производителем или сдать устройство в ближайший пункт по утилизации.  
3. Не разбирать аккумулятор, не модифицировать.  
4. Не подвергать аккумулятор воздействию влаги. Хранить в сухом месте.  
5. Использовать только кабель, прилагаемый к устройству или аналогичный кабель высокого качества.  
6. Неправильное использование устройства может привести к нагреву, воспламенению продукта и серьезным травмам. В случае возникновения неисправностей, прекратить использование БЗУ и свяжитесь с поставщиком.  
Мы приложили все усилия для того, чтобы информация в данном руководстве пользователя была максимально точной и полной. Неправильное использование продукта может привести к повреждению продукта, избыточному нагреву, возгоранию или взрыву, а также привести к серьезным травмам или материальному ущербу, за которые uBear (Производитель) не несет ответственности. uBear оставляет за собой право вносить любые изменения без дальнейших уведомлений в любые продукты.

### ■ Комплектация

▲ Аккумулятор × 1      ▲ Руководство по эксплуатации × 1  
▲ Micro-USB кабель × 1

### ■ Техническая поддержка и гарантии:

Просим обращаться на сайт [www.ubear-world.com](http://www.ubear-world.com) за технической поддержкой. Гарантийная информация представлена в размещенной ниже гарантийной карточке.

uBear Inc. California  
28 Valley st, Office 1045, Pasadena, CA 91105, USA Website  
[www.ubear-world.com](http://www.ubear-world.com)  
Phone +13238253023 E-Mail [usa@ubear-world.com](mailto:usa@ubear-world.com)

## ГАРАНТИЙНЫЙ ТАЛОН

1 год

### Условия

1. Продукция uBear подлежит гарантийному обслуживанию (включая материалы и качество изготовления) в течение 12 месяцев со дня покупки.  
2. uBear не предоставляет гарантийные услуги в любом из следующих случаев:  
дефект был вызван: неправильным использованием, небрежностью, несчастным случаем, неправильным использованием; несанкционированным ремонтом или модификацией товара; неподходящим электрическим напряжением или неправильным соединением.  
3. Все гарантийные услуги будут оказываться только после предоставления гарантийного талона для оригинальных продуктов, а также документа, подтверждающего покупку (чек) в том же регионе, где необходимо предоставить данную услугу.  
4. Если в течении гарантийного срока поставка каких-либо деталей для продукта была прекращена, замена может быть произведена подходящими деталями другой модели.  
5. uBear оставляет за собой право изменять условия без предварительного уведомления.